



Xyron® Sticker Maker



User Guide

Instant stickers.

Contents

Features _____	04
Product Overview _____	05
How to Use _____	06
Application Use _____	08
Helpful Tips _____	09

Features

Disposable sticker maker.



Don't wait.

Zero warm-up, cool-down, or dry-time.



Stay clean.

Get professional results without messy adhesives.

Product Overview

machine front and back



3" width
feed guide

Built-in
tear edge



How to Use

Features 20 feet of permanent adhesive.



1 Feed.

Feed your item into the sticker maker.



2 Pull.

Pull item completely through the sticker maker. Use the built-in tear edge to tear off the sticker.



3 Peel.

Remove the clear film and peel your sticker off the paper.

Acid-free. Non-Toxic. Recycle when empty.

Making made easy.

Application Use




Permanent Adhesive



1

After tearing from the sticker maker, rub item to ensure full adhesive transfer.



2

Remove clear film.



3

Peel sticker from paper backing and apply.

Helpful Tips

General Tips:

- For best results, pull item through slowly.
- Use items that are 1/8" thick or less.
- Feed and pull multiple items before tearing to maximize cartridge use.
- When feeding multiple items, do not overlap to ensure edge-to-edge coverage.
- Store in a cool, dry place.
- Use a variety of materials: paper, cardstock, vellum, canvas, burlap, fabric, ribbon, twill, twine, craft foam, tissue paper, felt, cork, wood, buttons, acrylic, photos, paper flowers, and newspaper.
- Remove excess adhesive with your finger or Xyron® Adhesive Eraser (sold separately).
- This is a disposable Sticker Maker and you do not refill it. You may take apart to dispose of all the pieces.

Fabric Tips:

- Wash sizing from fabric.
- For items that will be washed, stitch after adhering.



www.xyron.com

